### Isolated Standard Signal Conditioners

### VariTrans P 15000

The professional signal conditioners. With calibrated range selection and broad-range power supply.



#### The Task

Industrial applications require the transmission and conversion of various standard signals (0 ... 20 mA, 4 ... 20 mA and 0 ... 10 V) with maximum precision.

#### **The Problems**

Long transmission paths can cause potential differences that lead to errors in the measuring result. Different products were also required for different signals and supply voltages.

#### **The Solution**

The VariTrans P 15000 signal conditioners feature excellent transmission quality combined with calibrated standard signal switching using DIP switches and a broad-range power supply.

#### The Housing

At a width of just 12.5 mm, the modular housing with pluggable screw terminals allows for simple and fast assembly and pre-wiring of enclosures. Housings with fixed screw terminals are also available for extremely high mechanical loads.

The easy-to-open housing allows for simple configuration of the input and output ranges and provides good protection against contact and unintentional adjustment.

#### **The Advantages**

The analog transmission of the measurement signal with transformer isolation and the new digitally controlled range selection guarantee almost perfect signal transmission:

- Gain error only 0.08 %
- Excellent pulse formation
- Extremely low residual ripple
- Maximum long-term stability and reliability

#### The Technology

A microcontroller monitors the control element settings and controls the calibrated range selection. Interference with the signal transmission – due to contact resistance in the range switch, for example – is ruled out in this manner.

Thanks to the VariPower power supply for all common supply voltages from 20 to 253 V AC/DC, the devices can be used internationally with virtually all supply voltages. The extremely low power consumption and the related minimal self-heating significantly increase reliability. The result: a 5-year warranty.




#### **Facts and Features**

- Flexible and extremely precise
  Calibrated range selection without
  complicated readjustments
- Broad-range power supply VariPower 20 ... 253 V AC/DC
- Extremely compact design
  12.5 mm modular housing;
  up to 80 active isolators per meter
  of mounting rail
- **Quick and easy configuration** Housing can be easily opened
- Pluggable screw terminals
  Simple, time-saving assembly and prewiring of enclosures

- 3-port separation
  Protection against incorrect
  measurements or damage
- Maximum accuracy
- Specific test report following EN 10204 2.2
- Protective separation according to EN 61140 protects against unpermitted high voltages
- Maximum reliability
  No repair and failure costs
- 5-year warranty







# Isolated Standard Signal Conditioners

#### **Product Line**

Device	Input	Output	Order no.	Order no.
			with pluggable screw terminal	with fixed screw terminal
VariTrans P 15000	0 20 mA	0 20 mA	P 15000 H1	P 15000 F1
with calibrated switching of input and output	4 20 mA	4 20 mA		
	0 10 V	0 10 V		
VariTrans P 15000 with fixed settings	0 20 mA	0 20 mA	P 15016 H1	P 15016 F1
	0 20 mA	4 20 mA	P 15017 H1	P 15017 F1
	0 20 mA	0 10 V	P 15018 H1	P 15018 F1
	4 20 mA	0 20 mA	P 15026 H1	P 15026 F1
	4 20 mA	4 20 mA	P 15016 H1	P 15016 F1
	4 20 mA	010V	P 15028 H1	P 15028 F1
	0 10 V	0 20 mA	P 15036 H1	P 15036 F1
	0 10 V	4 20 mA	P 15037 H1	P 15037 F1
	0 10 V	0 10 V	P 15038 H1	P 15038 F1

#### Power supply

20 ... 253 V AC/DC



#### Specifications

Input data			
Inputs	0 20 mA 4 20 mA 0 10 V	terminal selectable / switchable (default setting 0 20 mA) or fixed setting (see product line)	
Input resistance	Current input Voltage input	voltage drop approx. 250 mV at 20 mA approx. 1 Mohm	
Overload capacity	Current input Voltage input	≤300 mA voltage limiting to 30 V by suppressor diode, max. allowable continuous current: 30 mA	
Output data			
Outputs	0 20 mAswitchable (default setting 0 20 mA)4 20 mAor fixed setting (see product line)0 10 V(transmission of negative signals up to approx5 % full scale)		
Load	with output current with output voltage	≤ 12 V (600 ohms at 20 mA) ≤ 10 mA (1 kohm at 10 V) <sup>1)</sup>	
Offset	20 μA or 10 mV		
Transmission behavior    Gain error <sup>1)</sup>	< 0.08 % meas.val. (DC)		
Cutoff frequency	> 10 kHz - 3 dB, P 15000 F1/H1 switchable to < 10 Hz -3 dB		
Response time T <sub>90</sub>	Approx. 70 μs with cutoff frequency 10 kHz		
Temperature coefficient <sup>2)</sup>	0.005 %/K full scale (reference temp. 23 °C)		
Power supply			
Power supply	20 253 V AC/DC	AC 48 62 Hz, approx. 2 VA DC approx. 0.9 W	
Isolation Galvanic isolation	3-nort isolation between	input output and power supply	
Test voltage	3-port isolation between input, output, and power supply 4 kV AC input against output against power supply		
Working voltage (basic insulation)	1000 V AC/DC with overvoltage category II and pollution degree 2 according to EN 61010-1. For applications with high working voltages, take measures to prevent accidental contact and make sure that there is sufficient distance or insulation between adjacent devices.		
Protection against electric shock	Protective separation to EN 61140 by reinforced insulation according to EN 61010-1. Working voltages up to 300 V AC/DC across input and output and power supply with overvoltage category II and pollution degree 2. For applications with high working voltages, take measures to prevent accidental contact and make sure that there is sufficient distance or insulation between adjacent devices.		

## Isolated Standard Signal Conditioners

#### Specifications (continued)

Surge withstand	5 kV, 1.2/50 μs, according to IEC 255-4			
EMC <sup>3)</sup>	EN 61326-1			
Approvals	CUL: File-No. E216767, Standards UL 61010-1, CSA-C22.2-95, No. 10101-1 GL: No. 14593-99 HH KTA: 3503 / 3507			
RoHS conformity	According to directive 2011/65/EU			
Further data				
MTBF <sup>4)</sup>	Approx. 91 years			
Ambient temperature	Operation:-10 +70 °CTransport and storage:-40 +85 °C			
Ambient conditions	Indoor use <sup>5)</sup> ; relative humidity 5 95 %, no condensation; max. altitude 2000 m (air pressure: 7901060 hPa) <sup>6)</sup>			
Design	Modular housing, 12.5 mm wide, see dimension drawings for further measurements, pluggable screw terminals: Type H1 fixed screw terminals: Type F1 Connection: pluggableH1 ; fixedF1 Conductor cross section max. 2.5 mm <sup>2</sup> Multi-wire connection max. 1 mm <sup>2</sup> (two wires with equal diameters)			
Tightening torque	0.7 Nm			
Ingress protection	IP 20			
Mounting	Metal interlock to attach to 35 mm DIN rail according to EN 60715			
Weight	Approx. 150 g			

<sup>1)</sup> Input 4 ... 20 mA: Offset switching not calibrated


<sup>2)</sup> Higher output load upon request

 $^{3)}$  Average TC in the specified operating temperature range -10 °C  $\ldots$  +70 °C

4) Slight deviations are possible while there is interference
 5) Mean time between failures – MTBF – according to EN 61709 (SN 29500). Conditions: Stationary operation in well-kept rooms,

average ambient temperature 40°C, no ventilation, continuous operation <sup>6)</sup> Closed, weather-protected operating areas (stationary operation), water or wind-driven precipitation (rain, snow, hail, etc.) excluded

<sup>7)</sup> Lower air pressure reduces the allowable working voltages.




#### **Block Diagram**



#### **Typical Applications**


#### **Potential isolation**

for safe connection of the measurement signals to the processing electronics




#### Signal conversion

e.g., to convert voltage signals into current signals for interference-free signal transmission over long distances



#### Load increase

e.g., for measurement signals with low load capability




## Isolated Standard Signal Conditioners

#### **Typical Applications** (continued)


#### **Signal multiplication**

e.g., for safe processing of the measurement signals by different devices



#### 2-wire operation


for easy configuration of 2-wire measurement circuits






#### **Dimension Drawings and Terminal Assignments**

#### Housing with pluggable screw terminals



Housing with fixed screw terminals



#### **Terminal assignments**

1	Input	+	Current
2	Input	_	Current

~	mput	_	Currer
3	Input	+	Voltac

- Input + Voltage 4 Input \_ Voltage
- + 5 Output
- Output
- 6 7
- Power supply AC/DC Power supply AC/DC 8

Conductor cross-section max. 2.5 mm<sup>2</sup>

Multi-wire connection max. 1 mm<sup>2</sup> (two wires with equal diameters)