### **ProLine**

# Interface Technology

# **Universal Isolated Signal Conditioners**

### VariTrans P 27000

The "Multimeter" among the signal conditioners.
With 480 switchable calibrated ranges and broad-range power supply.



#### The Task

A wide variety of measurement signals must be reliably galvanically isolated and converted into standardized signals. This applies to any input signals from  $\pm 20$  mV to  $\pm 200$  V and from  $\pm 0.1$  mA to  $\pm 100$  mA.

#### The Problem

The range of tasks results in too many different devices.

#### The Solution

The calibrated switching of the input and output ranges using DIP switches allows VariTrans P 27000 universal signal conditioners to be used without complicated readjustment. As switching occurs without expensive and unreliable equipment, the devices can also be easily configured on site.

The broad-range power supply for all common supply voltages from 20 to 253 V AC/DC offers maximum flexibility.

To make setting the required input and output ranges simple and user friendly, we offer a free software tool called VariSoft to support the user. VariSoft shows you the correct DIP switch position when you enter the required input and output ranges and it has an integrated print option for easy documentation.

You can download VariSoft free of charge from our website.



#### The Housing

At a width of just 12.5 mm, the modular housing with pluggable screw terminals allows for simple and fast assembly and pre-wiring of enclosures. Housings with fixed screw terminals are also available for extremely high mechanical loads.

The easy-to-open housing allows for simple configuration of the input and output ranges and provides good protection against contact and unintentional adjustment.

14 | Knick > VariTrans P 27000



#### The Advantages

The analog transmission of the measurement signal with transform-er-based isolation and the digitally controlled range selection guarantee almost perfect signal transmission:

- Gain error only 0.08 %
- Excellent pulse formation
- Extremely low residual ripple
- Maximum long-term stability and reliability

#### The Technology

A microcontroller monitors the control element settings and controls the calibrated range selection. Interference with the signal transmission – due to contact resistance in the range switch, for example – is ruled out in this manner.

Thanks to the VariPower power supplies, the devices can be used internationally with virtually all supply voltages. The extremely low power consumption and the related minimal self-heating significantly increase reliability. The result: a 5-year warranty.

#### **Facts and Features**

- Flexible and extremely precise
   Calibrated range selection without
   complicated readjustments
- Broad-range power supply
   VariPower 20 ... 253 V AC/DC
- Compact design
   12.5 mm modular housing;
   up to 80 active isolators per meter of mounting rail
- Quick and easy configuration
   Housing can be easily opened
- Pluggable screw terminals
   Simple, time-saving assembly and prewiring of enclosures
- 3-port separation
   Protection against incorrect measurements or damage

- Maximum accuracy
- Specific test report
   Following EN 10204 2.2
- Protective separation

According to EN 61140. Protection against unacceptably high voltages (for example, with shunt measurements at high potentials or in 3-phase systems)

- Maximum reliability
   No repair and failure costs
- 5-year warranty













VariTrans P 27000 Knlck > | 15

# **ProLine** Interface Technology

# Universal Isolated Signal Conditioners

#### **Product Line**

Device	Input	Output	Order no.	Order no.
			with pluggable screw terminal	with fixed screw terminal
VariTrans P 27000 Input and output adjustable	0 ±20 mV/200 V	0 20 mA	P 27000 H1	P 27000 F1
	0 ±0.1 mA/100 mA	4 20 mA		
		0 10 V		
		0 ±10 V		
		0 ±20 mA		
/ariTrans P 27000	0 ±20 mA	0 ±20 mA	P 27016 H1	P 27016 F1
with fixed settings	0 ±20 mA	0 ±10 V	P 27018 H1	P 27018 F1
	0 ±60 mV	0 ±20 mA	P 27056 H1	P 27056 F1
	0 60 mV	4 20 mA	P 27057 H1	P 27057 F1
	0 ±60 mV	0 ±10 V	P 27058 H1	P 27058 F1
	0 ±150 mV	0 ±20 mA	P 27066 H1	P 27066 F1
	0 150 mV	4 20 mA	P 27067 H1	P 27067 F1
	0 ±150 mV	0 ±10 V	P 27068 H1	P 27068 F1
	0 ±300 mV	0 ±20 mA	P 27076 H1	P 27076 F1
	0 300 mV	4 20 mA	P 27077 H1	P 27077 F1
	0 ±300 mV	0 ±10 V	P 27078 H1	P 27078 F1
	0 ±500 mV	0 ±20 mA	P 27086 H1	P 27086 F1
	0 500 mV	4 20 mA	P 27087 H1	P 27087 F1
	0 ±500 mV	0 ±10 V	P 27088 H1	P 27088 F1
	0 ±1 V	0 ±20 mA	P 27096 H1	P 27096 F1
	0 1 V	4 20 mA	P 27097 H1	P 27097 F1
	0 ±1 V	0 ±10 V	P 27098 H1	P 27098 F1
	0 ±10 V	0 ±20 mA	P 27036 H1	P 27036 F1
	0 ±10 V	0 ±10 V	P 27038 H1	P 27038 F1
VariTrans P 27000 with fixed settings to customer requirements	0 ±1 V	0 ±10 V	P 27000 H1-nnnn	P 27000 F1-nnn
Accessories			Order no.	Order no.
VariSoft SW 108	Adjustment tool for the adjustable VariTrans P 27000 universal signal conditioners		SW 108	SW 108

Power supply

20 ... 253 V AC/DC

16 | Knick > VariTrans P 27000



### **Specifications**

Input data				
Inputs	P 27000 H1/F1: Voltage Current	Default setting ±10 V configurable from 20 mV to 200 V and switchable in calibrated increments of 60 mV, 100 mV, 150 mV, 300 mV, 500 mV, 1 V, 5 V, 10 V, 100 unipolar/bipolar configurable from 0.1 mA to 100 mA and switchable in calibrated increments of 1 mA, 5 mA, 10 mA, 20 mA, 50 mA, unipolar/bipolar and		
	4 20 mA <sup>1)</sup>			
Input resistance	Current input	Ranges ≤ 5 mA Ranges > 5 mA	approx. 100 ohms approx. 5 ohms	
	Voltage input	approx. 1 Mohm		
Overload capacity	Current input	Ranges ≤ 5 mA	≤ 100 mA	
	Voltage input	Ranges > 5 mA Ranges ≤ 500 mV	≤300 mA Limiting by 36 V suppressor diode,	
		Ranges > 500 mV	max. allowable continuous current ≤ 20 mA Limiting by 250 V suppressor diode, max. allowable continuous current ≤ 3 mA	
Output data				
Output	P 27000 H1/F1: Default setting ±10 V 20 mA, 5 V, 10 V unipolar/bipolar and 4 20 mA, 1 5 V and 2 10 V calibrated switching			
Offset	-100 %, -50 %, 0 %, 50 %, 100 % span of selected output range, calibrated switching			
Load	with output current $\leq 12 \text{ V (600 ohms at 20 mA)}$ with output voltage $\leq 10 \text{ mA (1 kohm at 10 V)}^2$			
Offset	20 μA or 10 mV			
Residual ripple	< 10 mV <sub>rms</sub>			
Transmission behavior				
Adjustment range ZERO potentiometer	±25 % span of selected output range			
Adjustment range SPAN potentiometer	$0.33 \dots 3.30  x$ final value of selected input range (max. $V_{in} = 200  V$ )			
Gain error	< 0.08 % meas.val. (DC)			
Cutoff frequency	P 27000 H1/F1: > 10 kHz, < 10 Hz, switchable -3 dB, fixed-range models > 10 kHz, -3 dB			
Response time T <sub>90</sub>	Approx. 70 μs with cutoff frequency 10 kHz adjusted			
Temperature coefficient <sup>3)</sup>	< 0.005 %/K full scale (reference temp. 23 °C)			
Power supply				
Power supply	20 253 V AC/DC; AC 48 62 Hz, approx. 2 VA; DC approx. 0.9 W			

VariTrans P 27000 **Knlck →** | 17

# **ProLine** Interface Technology

# **Universal Isolated Signal Conditioners**

#### **Specifications** (continued)

Isolation			
Galvanic isolation	3-port isolation between input, output, and power supply		
Test voltage	5 kV AC input against output; 4 kV AC output against power supply		
Working voltage (basic insulation)	1000 V AC/DC with overvoltage category II and pollution degree 2 according to EN 61010-1. For applications with high working voltages, take measures to prevent accidental contact and make sure that there is sufficient distance or insulation between adjacent devices.		
Protection against electric shock	Protective separation to EN 61140 by reinforced insulation according to EN 61010-1.  Working voltages with overvoltage category II and pollution degree 2:  up to 600 V AC/DC across input and output  up to 300 V AC/DC across output and power supply  up to category II and degree 2  For applications with high working voltages, take measures to prevent accidental contact and make sure that there is sufficient distance or insulation between adjacent devices.		
Explosion protection	Europe: II 3G Ex nA IIC T4 Gc X USA: Class I Div.2 GRP A,B,C,D T4 Class I Zone 2 AEx nA IIC T4 Canada: Class I Zone 2 Ex nA IIC T4 XClass I Div.2 GRP A,B,C,D T4		
Standards and approvals			
Surge withstand	5 kV, 1.2/50 μs, according to IEC 255-4		
EMC <sup>4)</sup>	EN 61326-1		
Approvals	CUL:       cULus Listed, File No. E340287, E308146, E340288         Standard:       UL 61010-1 and CAN/CSA C22.2 No. 61010-1         GL:       No. 42843-02 HH         KTA:       3507 not in combination with explosion protection		
RoHS conformity	According to directive 2011/65/EU		
Further data			
MTBF <sup>5)</sup>	Approx. 76 years		
Ambient temperature	Operation: $-10 \dots +70 ^{\circ}\text{C}$ Transport and storage: $-40 \dots +85 ^{\circ}\text{C}$		
Ambient conditions	Indoor use <sup>6)</sup> ; relative humidity 5 95 %, no condensation; max. altitude 2000 m (air pressure: 790 1060 hPa) $^{7)}$		
Design	Modular housing, 12.5 mm wide, see dimension drawings for further measurements, pluggable screw terminals: Type H1; fixed screw terminals: Type F1 Connection: pluggable screw terminals H1; fixed screw terminals F1 Conductor cross section max. 2.5 mm²; Multi-wire connection max. 1 mm² (two wires with equal diameters)		
Tightening torque	0.7 Nm		
Mounting	Metal interlock to attach to 35 mm DIN rail according to EN 60715		
Weight	Approx. 150 g		

<sup>1)</sup> Input 4 ... 20 mA: Offset switching not calibrated

18 | **Knick** > VariTrans P 27000


<sup>2)</sup> Higher output load upon request

 $<sup>^{3)}</sup>$  Average TC in the specified operating temperature range -10 °C  $\dots$  +70 °C

<sup>&</sup>lt;sup>4)</sup> Slight deviations are possible while there is interference

<sup>5)</sup> Mean Time Between Failures – MTBF – according to EN 61709 (SN 29500). Conditions: Stationary operation in well-kept rooms, average ambient temperature 40°C, no ventilation, continuous operation
6) Closed, weather-protected operating areas (stationary operation), water or wind-driven precipitation (rain, snow, hail, etc.) excluded
7) Lower air pressure reduces the allowable working voltages.


#### **Block Diagram**



### **Typical Applications**


#### **Potential isolation**

for safe coupling of the measurement signals to the processing electronics



### Signal conversion or range adjustment

for converting arbitrary measurement signals into standard 10 V or 20 mA signals



VariTrans P 27000 **Knick →** 19

# **ProLine**


# Interface Technology

# **Universal Isolated Signal Conditioners**

**Typical Applications** (continued)


### Simple shunt measurement

### e.g., including any settings for overload ranges



#### **Potential isolation**

for safe connection of the measurement signals to the processing electronics




20 | Knick > VariTrans P 27000




#### **Dimension Drawings and Terminal Assignments**

### Housing with pluggable screw terminals



### Housing with fixed screw terminals



### **Terminal assignments**

1 Input + current > 5 mA

2 Input + current  $\leq$  5 mA, voltage  $\leq$  500 mV

3 Input + voltage > 500 mV

4 Input –
5 Output +
6 Output –
7 Power supply AC/DC

Fower supply AC/DC

8 Power supply AC/DC

Conductor cross section max. 2.5 mm<sup>2</sup>

Multi-wire connection max. 1 mm<sup>2</sup> (two wires with equal diameters)