ProLine Interface Technology





The Task

Isolation and transmission of 0(4) ... 20 mA and 0 ... 10 V standard signals in two 0(4) ... 20 mA output channels with galvanic isolation between input, outputs and power supply.

The Problems

Measuring and control engineering frequently requires an analog standard signal to be processed at two points, i.e., by two devices, with both devices needing to receive the same signal. To prevent falsified signals and in particular, in the event of errors, interaction or even damage, it makes sense to isolate signals and devices galvanically from one another.

The Solution

The VariTrans A 20300 signal doubler is an extremely compact product which also provides a cost-effective solution to the problem. In this module, the input, both outputs, and the power supply are safely decoupled from one another (four-port isolation).

VariTrans A 20300

Signal doublers with two switchable calibrated outputs in a 6 mm housing, also for applications with high output loads.

The Housing

Measuring only 6 mm, the ultra-slim, closed 8-pin modular housing of the VariTrans A 20300 takes up only a little space on the DIN rail and, if necessary, can be installed at a later date.

The Advantages As a Signal Doubler:

In addition to "doubling" the analog signal, the VariTrans A 20300 can also convert signals if required. If, for example, the signal source only has a voltage output but current signals are used in the system, then the signal doubler converts the voltage signal (0 ... 10 V) proportionally into the required current signals (0 ... 20 mA or 4 ... 20 mA). Conversion from "Dead Zero" (0 ... 20 mA) to "Live Zero" (4 ... 20 mA) is also possible. The corresponding input and output signals are calibrated and can be selected using DIP switches, with the two outputs being switched over together.

To Increase the Load:

The VariTrans A 20300 can also be used when a particularly high output load is required. Standard signal sources can often drive a load of up to 500 ohms, i.e., supply 10 V at 20 mA. Sometimes certain devices – e.g., actuators – require a higher voltage; i.e., their input resistance is higher. The signal doubler can also solve this problem: Both output signals are not used separately in this case, but are connected in series to form one signal. This doubles the available voltage, making it possible to drive a higher load of up to 1000 ohms (20 V at 20 mA). Of course, the signal-defining 0/4 to 20 mA current is retained in the series configuration.

The Technology

To implement the high level functionality of an A 20300 in the smallest of spaces - in a 6-mm wide modular housing with correspondingly small volume - a patent-pending circuit design is used. The energy balance (two active outputs) in particular must be optimized for all operating conditions. A patent application has been filed for the circuit principles of the VariTrans A 20300. Like all VariTrans A 20xxx series products, the signal doubler also provides protective separation according to EN 61140 to ensure high-level protection of personnel and equipment. This is achieved by means of increased insulation in compliance with EN 61010-1. In spite of being only 6 mm wide, the VariTrans A 20300 makes no compromises regarding its insulation properties.



VariTrans A 20300

Facts and Features

- Safety in the smallest space
 4-port isolation in 6 mm modular housing
- Signal doubling combined with signal conversion
- Load increase up to 1000 ohms possible for inputs with high input impedances
- Standards-compliant personal protection
 through protective separation according to EN 61140
- Flexible use with DIP switches accessible from the outside
- Calibrated range selection without complicated trimming

The power supply can be routed from one device to another via DIN rail bus connectors. Low-cost solution
 Only one compact, low-cost device is required instead of two conventional isolators

5 Year

Warranty

- International use UL/CSA approvals
- 5-year warranty



Product Line

Device	Input	Output	Order no.
VariTrans A 20300 calibrated switching (both outputs together)	0 20 mA	0 20 mA, 10 V	A 20300 P0
	4 20 mA	4 20 mA, 10 V	
	0 10 V		

Power supply

24 V DC

Accessories Order no. ZU 0628 ZU 0628 Power supply bridging for 2 isolators, DIN rail bus connector A 20xxx P0 or P 32xxx P0 IsoPower A 20900 Power supply, 24 V DC, 1 A (see page 212) A 20900 H4 ZU 0677 power terminal block For connecting the 20 ... 30 V DC supply voltage ZU 0677 to the ZU 0628 DIN rail bus connector DIN rail bus connector for tapping of supply voltage ZU 0678 (2 units required if on right side of IsoPower A 20900)

ProLine Interface Technology

Signal Doublers

Input data				
Input	0 20 mA, 4 20 mA, 0 10 V switchable (default setting 0 20 mA)			
Input resistance	Current input: Voltage input:	voltage drop \leq 0.1 V at 20 mA (with power failure approx. 350 mV) approx. 100 k Ω		
Overload capacity	Current input: Voltage input:	self-resetting overcurrent protection (PTC characteristic) voltage limited to 30 V by suppressor diode, max. permitted continuous current: 3 mA		
Output data				
Outputs 1 and 2	0 20 mA, 4 20 mA jointly switchable (default setting 0 20 mA)			
Load	\leq 10 V (\leq 500 Ω at 20 mA), \leq 20 V (both outputs in series)			
Offset	<30 µA	<30 μΑ		
Residual ripple	< 10 mV _{rms} (at 500 Ω load)			
Transmission behavior				
Gain error ¹⁾	< 0.2 % meas. val. with direct current transmission 1:1 < 0.3 % meas. val. with voltage input			
Cutoff frequency	> 100Hz			
Response time	T ₉₀ : approx.1 ms; T ₉₉ : approx. 1.5 ms			
Temperature coefficient ²⁾	< 0.01 %/K full scale (reference temp. 23 °C)			
Power supply				
Power supply	24 V DC (\pm 15 %), approx. 1.2 W The power supply can be routed from one device to another via DIN rail bus connectors.			
Isolation				
Galvanic isolation	4-port isolation betwe	een input, outputs and power supply		
Test voltage		er supply against input uts against each other and against input/power supply		
Working voltage (basic insulation)	For applications with	ross all circuits with overvoltage category II and pollution degree 2. high working voltages, take measures to prevent accidental contact ere is sufficient distance or insulation between adjacent devices.		
Protection against electric shock	Working voltage up to category II and polluti For applications with	paration to EN 61140 by reinforced insulation according to EN 61010-1. age up to 300 V AC/DC across each output and all other circuits with overvoltage d pollution degree 2. ns with high working voltages, take measures to prevent accidental contact e that there is sufficient distance or insulation between adjacent devices.		



VariTrans A 20300

Specifications (continued)

Standards and approvals			
EMC ³⁾	Product family standard: Emitted interference: Immunity to interference:	EN 61326 Class B Industrial environment	
Approval	cURus, file no. E 220033, standards: UL 508 and CAN/CSA 22.2 No. 14-95		
RoHS conformity	According to directive 2011/65/EU		
Further data			
MTBF ⁴⁾	Approx. 243 years		
Ambient conditions	Indoor use ⁵⁾ ; Relative humidity 5 95 %, no condensation; max. altitude 2000 m (air pressure: 7901060 hPa) ⁶⁾		
Ambient temperature	During operation: During storage:	0 +55 ℃ when mounted in row -25 +85 ℃	
Design	Modular housing with screw terminals, width 6.2 mm		
Conductor cross sections	Single wire 0.2 2.5 mm ² Stranded wire 0.2 2.5 mm 24-14 AWG	12	
Tightening torque	0.6 Nm		
Ingress protection	IP 20		
Mounting	For 35-mm DIN rail according to EN 60715		
Weight	Approx. 50 g		

¹⁾ Additional error for live-zero operation 20 μA
 ²⁾ Average TC in the specified operating temperature range 0°C ... +55 °C
 ³⁾ Slight deviations are possible while there is interference
 ⁴⁾ Mean time between failures – MTBF – according to EN 61709 (SN 29500). Conditions: stationary operation in well-kept rooms,

average ambient temperature 40°C, no ventilation, continuous operation

⁵⁾ Closed, weather-protected operating areas (stationary operation), water or wind-driven precipitation (rain, snow, hail, etc.) excluded

⁶⁾ Lower air pressure reduces the allowable working voltages.

ProLine Interface Technology

Signal Doublers

Block Diagram



Typical Applications

Signal doubling



Load increase





VariTrans A 20300

Dimension Drawing and Terminal Assignments



Terminal assignments

1	Output 2	+
2	Output 2	_
3	Input	+

- Output 2 –
- Input +
- 4
- Input Output 1 +
- 5 6
- Output 2 Power supply + 7
- 8 Power supply -

Conductor cross-sections: 0.2 ... 2.5 mm² single wire stranded wire 0.2 ... 2.5 mm² 24-14 AWG

All dimensions in mm